ChromeOS Demo Mode

Installation and reset guide



About this guide

This guide will show you how to install and remove the ChromeOS demo mode on any ChromeOS device. The guide contains four different sections running you through the whole process.

To perform an installation of the ChromeOS Demo Mode you will need:

- A ChromeOS device that is running ChromeOS M105 or later
- A WiFi connection
- About 15 to 20 minutes of your time





Important: Before we begin



Before you begin with the installation process you need to make sure that the ChromeOS device is running on **ChromeOS version M105 or later**.

If the device is running ChromeOS M105 or later: continue to section 2 (Page 12)

If the device is running a ChromeOS version earlier than M105: continue to section 1 (Page 5)

If you are unsure which version the device is running: continue to section 1 (Page 5)




Table of contents

Section 1:	Performing an update on a Chromebook	Page 3
Section 2:	Installing the Demo Mode	Page 12
Section 3:	Performing a Powerwash (reset) on a Chromebook that is using Demo Mode	Page 18
Section 4:	Troubleshooting	Page 37





Performing updates












 Select your desired language and press 'Get Started' to continue.






3. Now connect to the wifi network of the store.

If the wifi network requires a password you can ask a retail sales associate for assistance.


!!! Try to avoid non-protected guest networks for the best experience.



4. The next step is to agree with the terms and conditions.

You can select or deselect the option to send usage and diagnostic data and press 'Accept to continue' to continue the setup.





5. On the next screen we can **select 'Browse** as **Guest'** in the bottom left corner to enter the guest account on the ChromeOS device.




6. You are now using the guest account on the ChromeOS device.





7. Go into the quick settings menu by clicking on the time in the bottom right corner.


Next press the settings cog icon at the top of the window.




8. The settings menu now pops-up.

Here you can select 'About ChromeOS'.








You can check for updates by **clicking on 'Check for updates'**.


!!! You need to make sure the device is running ChromeOS M105 or later.




10. The device will now download the latest updates if there are any available.

!!! If the device is already up-to-date you can perform a Powerwash and start installing the Demo Mode. (See section 3 for Powerwash instructions)





11. After the update has been successfully downloaded you can press 'Restart' to restart the device and install the update.



12. The ChromeOS device has now successfully been updated. You can now start the installation of the Demo Mode.

!!! To make sure your device is running the latest version of ChromeOS you can always go back into the Guest account and double check.








1. First boot up the device.

!!! If you want to boot up a Chromebook for the first time after taking it out of the box you'll need to plug-in the charger first to activate the battery.




2. On the start screen you simultaneously press the CTRL + ALT + D keys.

OR


Tap the middle of the screen ten times repeatedly.

!!! If you end up on the wifi selection screen after booting up the ChromeOS device you first need to perform a Powerwash (see section 2)





3. On the screen that now pops-up press 'OK' to confirm enabling the Demo Mode.




4. Now connect to the wifi network of the store.


If the wifi network requires a password you can ask a retail sales associate for assistance.

!!! Try to avoid non-protected guest networks for the best experience.






5. On the next screen select the desired country and (optionally) put in a Retailer-store ID code.



The device will now check for any updates. After the check is finished you can click 'Next' to continue.


!!! If your device needs to update it will automatically install the update, reboot and bring you back to the start screen.





7. The next step is to agree with the terms and conditions.


You can select or deselect the option to send usage and diagnostic data and click 'Accept to continue' to continue the setup.



8. After accepting the terms and conditions the device will download the needed recources and start enrolling the device into the Demo Mode.

!!! If the device is connected to a slow(er) wifi network this step could take a while. Give it some time and make sure to **not** turn off the device.





9. You are now finished, the Demo Mode has successfully been installed.



Powerwash



Table of contents

Powerwashing a Chromebook (Legacy)	Page 20
Powerwashing a Chromebook (New)	Page 24
Powerwashing a ChromeOS Tablet (Legacy)	Page 28
Powerwashing a ChromeOS Tablet (New)	Page 33



1. First we need to boot the Chromebook into the ChromeOS recovery

We do this by first turning off the Chromebook.

When the Chromebook is turned off you simultaneously press and hold the ESC (1) and Refresh (2) keys.

Whilst holding these keys you press the **power button (3)** to turn the Chromebook back on.










On the ChromeOS Recovery screen you simultaneously press the CTRL + ALT + D keys.

If ChromeOS is corrupted or damaged you can now use a Recovery USB stick or SD-card to Powerwash and recover the Chromebook (see section X).



The Chromebook will now ask if you want to turn off OS verification.

Confirm this by pressing the ENTER key.





4. OS verification is now turned off.

Press the SPACEBAR to re-enable OS verification.




 On the next screen press ENTER to confirm re-enabling OS verification and clear all local data and settings.





6. OS verification is now back on.

The Chromebook will now reboot and wipe all local data and settings.



7. After the process has been completed the Chromebook will boot back up.

The Chromebook is now ready to be setup again.



1. First we need to boot the Chromebook into the ChromeOS recovery


We do this by first turning off the Chromebook.

When the Chromebook is turned off you simultaneously press and hold the ESC (1) and Refresh (2) keys.

Whilst holding these keys you press the **power button (3)** to turn the Chromebook back on.








2. You should now see the ChromeOS Recovery screen.

Use the arrow keys on the keyboard to **select** "Advanced options" and press the ENTER key to confirm.


!!! If ChromeOS is corrupted or damaged you can now use a Recovery USB stick or SD-card to Powerwash and recover the Chromebook (see section X).



3. You are now in the "Advanced options" menu


Use the arrow keys to **select "Enable developer mode"** and press the **ENTER key** to confirm.





4. The Chromebook will now ask to confirm enabling Developer mode.


Use the arrow keys to **select "Confirm"** and press the **ENTER key** to confirm.




5. You are now in developer mode.

Use the arrow keys to **select "Return to secure mode"** and press the **ENTER key** to confirm.








Use the arrow keys on the keyboard to **select** "Confirm" and press the ENTER key to confirm.

The Chromebook will now reboot and clear all data and settings.



 After the process has been completed the Chromebook will boot back up.

The Chromebook is now ready to be setup again.



First we need to boot the ChromeOS
 Tablet into the ChromeOS recovery.

We do this by first turning off the ChromeOS Tablet.


When the ChromeOS Tablet is turned off you simultaneously press and hold the volume up and down (1) buttons.

Whilst holding these buttons you press and hold the **power button (2)** until the ChromeOS Tablet turns back on.

!!! You can't use the detachable keyboard during this process, you can detach it to make handling the device a bit easier.









Now press the **volume up and down buttons** simultaneously to enter the Advanced options menu.

!!! If ChromeOS is corrupted or damaged you can now use a Recovery USB stick or SD-card to Powerwash and recover the Chromebook (see section X).



3. You are now in the "Advanced options" menu






4. Use the volume up button to go up and select "Confirm Disabling OS Verification" and press the power button to confirm.



5. You will now be brought back to the "Advanced options" menu.






6. Use the volume up button to go up and select "Enable OS verification" and press the power button to confirm.



7. The ChromeOS Tablet will now ask to confirm enabling OS verification.


Use the volume buttons to select "Confirm enabling OS verification" and press the power button to confirm.





8. OS verification is now back on.

The ChromeOS Tablet will now reboot and wipe all local data and settings.



After the process has been completed the Chromebook will boot back up.

The Chromebook is now ready to be setup again.



1. First we need to boot the ChromeOS Tablet into the ChromeOS recovery.

We do this by first turning off the ChromeOS Tablet.

When the ChromeOS Tablet is turned off you simultaneously press and hold the volume up and down (1) buttons.

Whilst holding these buttons you press and hold the **power button (2)** until the ChromeOS Tablet turns back on.


!!! You can't use the detachable keyboard during this process, you can detach it to make handling the device a bit easier.








- 2. You should now see the ChromeOS Recovery screen.
 - Use the voulme buttons to **select "Advanced options"** and press the **power button** to confirm.
- !!! If ChromeOS is corrupted or damaged you can now use a Recovery USB stick or SD-card to Powerwash and recover the Chromebook (see section X).




- 3. You are now in the "Advanced options" menu
 - Use the voulme buttons to select "Enable developer mode" and press the power button to confirm.








Use the voulme buttons to **select "Confirm"** and press the **power button** to confirm..



5. You are now in developer mode.

Use the voulme buttons to select "Return to secure mode" and press the power button to confirm.






 The ChromeOS Tablet will now ask to confirm returning to secure mode. This will clear all data and settings.

Use the voulme buttons to **select "Confirm"** and press the **power button** to confirm.

The ChromeOS Tablet will now reboot and clear all data and settings.



 After the process has been completed the ChromeOS Tablet will boot back up.

The Chromebook is now ready to be setup again.



Troubleshooting

